


ITALIAN SMALL ROSE PRIVACY SET


Recommended latch code 1172

Product codes:



8207 | 8217 | 8227 | 8237 | 8241 | 8257





1. Measure the door thickness and mark the centre at the desired height for the latch.
2. Drill a 25mm (1") diameter hole through the door edge to a depth of at least 80mm. Ensure this hole is square to the door.
3. Mark the face of the door each side for drilling a 25mm diameter spindle hole. Mark two 5mm screw holes at 12 o'clock and 6 o'clock vertical positions at 42mm crs. The centre of the spindle hole will need to be 57mm from the door edge (backset). For clean cut-outs, drill from both sides, meeting in the middle of the door.



4. Insert the latch, scribe around the faceplate, remove, then chisel out recess to enable the latch faceplate to sit flush with the door edge.
5. Remove any loose saw dust and insert the latch, attach the faceplate and secure with the wood screws provided.




6. Insert the spindle into the latch so an even amount protrudes on each side of the door. Ensure the grooved side of the spindle will align with the grub screws on the handles.
7. Insert the long through fixing screws through the face of the handle at two vertical positions and slide over the spindle on the door.



8. Insert the handle on the opposite side of the door over the spindle and tighten the long bolts through into the rose. Trim the bolts to the correct length if necessary.
9. Screw the rose covers onto the handles and tighten the grub screws on the side of the levers onto the spindle for each side of the door.

Note: The grub screws may need a re-tighten after a bedding-in period. We recommend medium strength thread-lock to be used, Windsor code:1276



10. Close the door against the frame and mark the latch position for fitting of the striker.
11. Router or chisel so the striker fits flush, allowing for the plastic dustbox behind the striker.
12. Secure the striker with the wood screws provided. Test the door and if necessary, adjust the striker anti-rattle tab to take up any rattle.




ITALIAN SMALL ROSE PRIVACY SET


Product codes:

8207 | 8217 | 8227 | 8237 | 8241 | 8257



To view an easy to follow how-to video for installing this product visit windsorhardware.co.nz/installation.





1. Measure the door thickness and mark the centre of the door edge at the desired height for the bolt.
2. Drill a 25mm (1") diameter hole through the door edge to a depth of at least 90mm. Ensure this hole is square to the door.
3. Mark the face of the door each side for drilling a 25mm diameter spindle hole. The centre of the spindle hole will need to be 57mm from the door edge (backset). Mark two screw holes at 21mm above and below the centre of the spindle hole. Drill the screw holes to 6mm to accept the threaded sleeves. For clean cut-outs, drill from both sides, meeting in the middle of the door.





4. Insert the bolt and faceplate, scribe around the faceplate, remove, then chisel out recess to enable the bolt faceplate to sit flush with the door edge.
5. Remove any loose saw dust and insert the bolt, attach the faceplate and secure it with the wood screws provided.




6. Insert the spindle into the bolt so an even amount protrudes on each side of the door. Ensure the grooved side of the spindle is aligned with the grub screws on the turn.




7. Insert the short through fixing bolts into the threaded sleeves (1). Then insert those sleeves through the face of the rose of the turn side. Slide the turn over the spindle and press against the door.



8. Slide the release on the opposite side of the door over the spindle and press against the door. Insert the long bolts through the face of the rose of the release side and tighten them into the threaded sleeves.
9. Screw the rose covers onto the roses and tighten the grub screw on the side of the turn onto the spindle.



Note: The grub screws may need a re-tighten after a bedding-in period. We recommend medium strength thread-lock to be used, Windsor code: 1276



10. Close the door against the frame and mark the latch position for fitting of the striker.
11. Router or chisel so the striker fits flush, allowing for the plastic dustbox behind the striker.
12. Secure the striker with the wood screws provided.