



STREAMLINE PASSAGE SET


Product codes: 7314 | 7319




1. Measure the door thickness and mark the centre at the desired height for the latch.
2. Drill a 25mm (1") diameter hole through the door edge to a depth of at least 90mm. Ensure this hole is square to the door.
3. Mark the face of the door each side for drilling a 25mm diameter spindle hole. The centre of the spindle hole will need to be 60mm from the door edge (backset). For clean cut-outs, drill from both sides, meeting in the middle of the door. Mark and drill two 6mm screw holes at 21mm above and below the centre of the spindle hole.



4. Insert the latch, scribe around the faceplate, remove, then chisel out recess to enable the latch faceplate to sit flush with the door edge.
5. Remove any loose saw dust, insert the latch and secure it with the wood screws provided.




6. For the round rose unscrew the rose covers from the levers, for the square rose pull the rose covers off the levers. Unscrew the bolts from the threaded sleeves.
7. Insert the spindle through the latch so an even amount protrudes on each side of the door. Ensure the grooved side of the spindle will align with the grub screws on the handles.



8. Insert the threaded sleeves into the oval holes in the back of the rose at two vertical positions. Screw the short bolts from the top of the rose through into the threaded sleeves.
9. Slide the handle over the spindle and press against the door.
10. Slide the handle on the opposite side of the door over the spindle and tighten the long bolts through the rose into the threaded sleeves.
11. Screw the rose covers onto the handles and tighten the grub screws on the side of the levers onto the spindle for each side of the door. For the square rose press on the rose covers and tighten the grub screws on the side of the rose.

Note: The grub screws may need a re-tighten after a bedding-in period. We recommend medium strength thread-lock to be used. Windsor code: 1276



12. Close the door against the frame and mark the latch position for fitting of the striker.
13. Router or chisel so the striker fits flush, allowing for the plastic dustbox behind the striker.
14. Secure the striker with the wood screws provided. Test the door and if necessary, adjust the striker anti-rattle tab to take up any rattle.

